Typenschlüssel : Versorgungsgerät

HVE04.2

Versorgungsmodul ohne geregelter Zwischenkreisspannung

INN 43.20-04-02
2000-05-29

Kurztext-Spalte →	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
Beispiel:	H	V	E	0	4	.	2	-	W	0	7	5	N																												

1. Produktgruppe
1.1 HVE . . . . . = HVE

2. Baureihe
2.1 4 . . . . . = 04

3. Ausführung
3.1 2 . . . . . = 2

4. Kühlart
4.1 Luft intern (durch eigebautem Lüfter) = W

5. Nennleistung
5.1 75 KW . . . . . = 075

6. Sonstige Ausführung
6.1 keine . . . . . = N

Bildbeispiel: HVE04.2



"Schutzvermerk DIN 34 beachten" - "Copyright reserved"

Rexroth Indramat GmbH
Bgm.-Dr.-Nebel-Straße 2 • D-97816 Lohr a. Main
Telefon (0 93 52) 40-0 • Telefax (0 93 52) 40-48 85

geändert: NM, Steg
geprüft: NM, Ehm
erstellt in: FreeHand 8.0

Daten- oder Maßangaben dienen nur der unverbindlichen Information über grundsätzliche Produktmerkmale !

Type code : Supply unit

HVE04.2

Supply module without regulated DC-bus voltage

INN 43.20-04-02
2000-05-29

Abbrev. Column →	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
Example:	H	V	E	0	4	.	2	-	W	0	7	5	N																													

1. Product group
1.1 HVE . . . . . = HVE

2. Line
2.1 4 . . . . . = 04

3. Design
3.1 2 . . . . . = 2

4. Cooling mode
4.1 Air, internal (with built-in blower). . . . = W

5. Nominal power
5.1 75 KW . . . . . = 075

6. Other design
6.1 none . . . . . = N

Illustration example: HVE04.2



"Schutzvermerk DIN 34 beachten" - "Copyright reserved"

Rexroth Indramat GmbH
Bgm.-Dr.-Nebel-Straße 2 • D-97816 Lohr a. Main
Telephone (0 93 52) 40-0 • Telefax (0 93 52) 40-48 85

revised: NM, Steg
proved: NM, Ehm
draw up in: FreeHand 8.0

Data and dimensions serve to inform about product characteristics and are not binding !

Doc: INN-43-20-T04-02-M02-HVE.fh8